


# USING YOUR CUCININO POD




## The Lid

There are three positions for the lid: closed, upright and fully backward. You can also take the lid out completely.

**To put the lid to any of the three positions:** Rotate the lid in the side panel slots all the way backward, closed, or rotate it upwards and slot it down into the vertical slot.

**To take the lid off:** From the closed and backward positions, turn the lid in the slots on the top of the side panels, to the opening and lift it out. From the upright position simply lift the lid out the opening in the slots


**To reattach the lid:** Put the back of the lid into the slots on the top of the side panels, and then turn the lid in the slots to any of the three positions.



## The Side tables

**To open the side tables:** Push down the catches located at the back, bottom of the side panel, holding the side tables against the side panel. Then pull up the side panel until you hear the hinges click into place and it is horizontal to the floor.


**To close the side tables:** Squeeze the leavers under the side table, attached to the hinges, and let the side table go so that it clicks into place against the side of the pod.



## The Catches

**To open the catch:** Lift up the bottom of the catch up to release and raise the top bar, then simply open the door.

**To close the catch:** Put the bar at the top of the catch over the hook, then push the bottom of the catch down to tighten it and close the catch.




## The Tap

**To start it:** Press down on the button on the top. The tap will light up and the water flow will start momentarily. To turn it off, simply press the button again.

**Removing the tap:** To remove the tap for charging or storage, pull the tap upwards so that it comes off the securing blocks. (It may be a bit stiff)

**To charge the tap:** The tap should have an initial 2-3 hr charge after which it will last for many days use. When recharging the light glows red until turning blue when fully charged. The charging cable comes with your pod.



## The Sink

The sink does not come out of the top shelf. The box like shape has been made to protect it from dents and damage. The chopping board fits into the top and slots down into it for use.